


## TBR21 A.4.6.1 Acceptance of breaks in the loop in a call attempt



### Settings :-

Feed resistance	= 850 ohms	Voltage	= 50v
Impedance	= off	Dial / 300R's	= off
Dial cadence	= X	R to E / osc i/p	= X
Feed / open / short	= as needed	Normal / reverse	= X
Ring / feed	= feed	Feeding Bridge	= off

X means "don't care"

The apparatus under test ( AUT ) is plugged into the FB-2, and the controls are set as shown.

Measure the feed current as required.